

Thanks for shopping with Jeco®

Espresso Resin Wicker Serving Cart in Three Layers Tray

SKU# ORI004-B / 15010364



IMPORTANT:

Please read all the instructions and warnings before assembling. In order to make the whole product adjust to the best, please install all the screws on the product before full tightening!

WARNING:

- _ Keep all children and pets away from assembly area. Children and pets should be supervised when they are in the area of the product construction.
- _ Keep assembly area at least 6 feet from any obstruction such as a fence, garage, house, overhanging branches, laundry line or electrical wires.
- _ Some parts may contain sharp edges. When assembling and using this product, basic safety precautions should always be followed to reduce the risk of personal injury and damage to the product. Please read all instructions before assembly and use.
- _ Check all bolts for tightness before use. **IMPORTANT** - check and tighten bolts often to keep them secure!
- _ The chairs are not to be used for standing purposes and will not function as a stool or step-ladder. Use on even surfaces only.







JECO

1-800-893-3006
Ontario, CA 91761





Made in China

If you have questions regarding this product, call
1-800-893-3006 Mon.-Fri. 9:00-5:00 PST
(California) and ask for our product specialists, or
e-mail: cs@jeco-inc.com
See many more products on the Internet!
www.jeco-inc.com

Parts List:


<p>A. Top shelf with Lip Qty: 1</p> 	<p>B. Flat Shelf Qty: 1</p> 	<p>C. Bottom Shelf with Lip Qty: 1</p> 
<p>D. Legs Qty: 4</p> 	<p>E. Locking Wheel Qty: 2</p> 	<p>F. Wheel Qty: 2</p> 

Hardware List:


<p>G. Screws(Φ6x12mm) Qty: 16</p> 	<p>H. Washers(Φ6mm) Qty: 16</p> 	<p>I. Allen Wrench Qty: 1</p> 	<p>J. Wrench Qty: 1</p> 
---	---	--	---


To Assemble:

Step 1



Step 2





Care & Maintenance:

SPILLS:

Immediately wipe up the spill using a white damp cloth. Repeat process if necessary until stain is gone. Allow cushion to air dry.

RESIN WICKER PRODUCT CARE:

Before using, clean the product completely with a soft dry towel. When not in use, wipe free of any dirt or loose objects, wash with a mild solution of soap and water; rinse thoroughly and dry completely. Do not use strong detergent or abrasive cleaners. Over time nuts and bolts can loosen. Occasionally, check nuts and bolts on all chairs and table, re-tighten if necessary.