




Thanks for shopping with Jeco®

# 4FT Cashmere Needle Tree

SKU# ST41 / 16010005



## Part List:

A. Tree Top Qty: 1 	B. Tree Bottom Qty: 1 	C. Tree Stand leg Qty: 3 
---	--	---

# JECO

1-800-893-3006  
Ontario, CA 91761

Made in China

If you have questions regarding this product, call  
1-800-893-3006 Mon.-Fri. 9:00-5:00 PST  
(California) and ask for our product specialists, or  
e-mail: [cs@jeco-inc.com](mailto:cs@jeco-inc.com)

See many more products on the Internet!

[www.jeco-inc.com](http://www.jeco-inc.com)


## To Assemble:

**Before you start to assemble your tree, choose a location near a wall outlet. Make sure the tree stand is placed on a level surface.**

**Step 1:** Choose a location near a wall outlet, insert the legs (C) of the tree stand and lay the stand on the floor, Slide the locking disk of the tree stand down until it snaps into place.




**Step 2:** Insert the bottom section of tree body (B) into the tree stand, and make sure the trunk stays straight, then insert the top section of tree body (A) into the bottom section of tree body (B)



**Step 3:** Shape the branches to your preference by working from the bottom to the top, When shaping the branches start with tips farthest from the pole. One to the right, one to the left, and one at the center of the main stem.,slightly upseep all branch tips for a uniform look.



**Step 4:** Do not illuminate until tree is fully assembled. Connect the plug (A1) of string with the end cord (B1) of string, Insert the plug(B2) of string into the wall outlet.(see illustration)



## Operation:

After the plugs are plugged into the wall outlet your entire tree should be lit. If some bulbs do not light, search for any loose plugs, broken, loose or missing bulbs that may have caused the problem. Replace bulbs promptly with replacement bulbs provided in order to maintain the performance and life expectancy of your tree.

**Step 1:** Connect the light strings of the tree together and plug the power cord into a wall outlet.

**Step 2:** If a bulb is blown, replace the faulty bulb following the diagram below.

Spare bulbs are included for easy replacement..



**Step 3:** If the tree comes with a foot pedal, step on the On/Off button.

## **WARNING-Risk of Fire and Electric Shock:**

1. Read all instructions and warning tags included with this tree.
2. For Indoor and Outdoor Use.
3. Do not place near gas or electric heaters, radiators, fireplaces, or other similar sources of heat.
4. Place on a level, hard, flat surface; do not place where tree is likely floors or thick carpeting.

## **WARNING-Risk of Fire and Electric Shock:**

5. Do not use candles on tree.
6. After assembly and adding decorations, make sure the tree is stable. If stable, shift the weight of the decorations, and use support wires to walls and/or window frames (make sure they are secure also).
7. Do not overload extension cords or power strips, see ratings on those devices and check the rating labels on the tree for compatibility.
8. Do not install near fountains, bathtubs, sinks, pools or other areas of standing water.
9. Only use this product with extension cords rated for indoor and outdoor use.

## **Care and Cleaning:**

**Step 1:** Remove all ornaments and decorations.

**Step 2:** Unplug the cord from the wall and then unplug each section of the tree.

**Step 3:** Gently lift the tree top straight up to remove from the center section and fold all brances towards the pole.

**Step 4:** Carefully place all tree sections into a shipping box and tape it shut.

**Step 5:** Store your tree in a cool, dry place away from sunlight.