
Thanks for shopping with $\operatorname{Jeco}^{^{\circledR}}$

Rusty Buddha Fountain with LED Light

SKU# FCL153 / 15030097



Parts List:





1-800-893-3006 Ontario, CA 91761 Made in China


If you have questions regarding this product, call 1-800-893-3006 Mon.-Fri. 9:00-5:00 PST (California) and ask for our product specialists, or e-mail: cs@jeco-inc.com

See many more products on the Internet!

www.jeco-inc.com


To Assemble:

Step 1: Attach the pre-assembled water hose to the pump (C) and attach the LED light (B) to the light cable comes out from the pump (C), at last, place the pump in the center of the bottom basin (A).




Step 2: Fill the product (A) with clean water, making sure the pump (C) is fully submerged.

Note: The maximum water level should be approximately 1.2 inches below the top edge of the basin (A).



Step 3: Finally, connect the plug of pump (C) to a GFCI outlet.

WARNING: Always disconnect the pump (C) before placing your hands in the water.



CARE AND MAINTENCE

•	To eliminate the possibility of water damage to areas around the fountain, check for
	leaks and excessive splashing after the initial set up of the fountain. It is highly
	recommended this fountain be placed in an area where it cannot be damaged.
•	Do not leave the fountain running for extended periods of time when no one is present
	to observe the performance.
•	Check the area around the fountain on a regular basis to ensure there is no leakage.
•	Do not attend to attempt to move fountain once filled with water.
	•