
Thanks for shopping with $Jeco^{^{\circledR}}$

Lion Head Fountain

SKU# FCL162 / 15030106



Part List:





1-800-893-3006 Ontario, CA 91761 Made in China


If you have questions regarding this product, call 1-800-893-3006 Mon.-Fri. 9:00-5:00 PST (California) and ask for our product specialists, or e-mail: cs@jeco-inc.com

See many more products on the Internet!


www.jeco-inc.com

To Assemble:


Step 1: Align top (A) with two set points on base (B). Then use bolts (AA) with washers (BB) to secure top (A) to base (B). Use a wrench (not included) to tighten the bolts, turning them clockwise. Attach pump (D) to water supply tube, resting pump (D) inside base (B). Route power cord of pump (D) out of the base (B).



Step 2: Attach platform (C) to base (B).



Step 3: Fill base (B) with clean water. Note: The maximum water level should be no higher than the water-level line on platform (C).



Step 4: Finally, connect plug of pump (D) to a GFCI outlet.

WARNING: Always disconnect the pump (D) before placing your hands in the water. Always disconnect the pump (D) before fill water into base (B).



CARE AND MAINTENCE

- To eliminate the possibility of water damage to areas around the fountain, check for leaks and excessive splashing after the initial set up of the fountain. It is highly recommended this fountain be placed in an area where it cannot be damaged.
- Do not leave the fountain running for extended periods of time when no one is present to observe the performance.
- Check the area around the fountain on a regular basis to ensure there is no leakage.
- Do not attend to attempt to move fountain once filled with water.