









Thanks for shopping with Jeco®

Ball Fountain with Led Light

SKU# FCL177 / 15030196



Parts List:

<p>A. Top Ball Qty: 1</p> 	<p>B. Bottom Base Qty: 1</p> 	<p>C. Pump and Adaptor Qty: 1</p> 	<p>D. Back cover Qty: 1</p> 
<p>E. Anti-Splash Net Qty: 1</p> 	<p>F. Led Light Qty: 1</p> 	<p>G. Led Light Qty: 1</p> 	

JECO

1-800-893-3006
Ontario, CA 91761

Made in China

If you have questions regarding this product, call
1-800-893-3006 Mon.-Fri. 9:00-5:00 PST
(California) and ask for our product specialists, or
e-mail: cs@jeco-inc.com

See many more products on the Internet!

www.jeco-inc.com


To Assemble:

Step 1:

A: Carefully attach the pump (C) to the hose that pre-assembled at the top ball, making sure to place the pump in the center of the bottom (B).


B: Carefully connect the two led light cables (F) and (G) to the light cable comes out from pump (C), making sure both parts connect securely.

C: Align the top ball (A) to the basin (B).



Step 2:

After place the pump inside the center of the bottom, please attach the back cover (D) to the back side of bottom base (B).




Step 3:

A: Attach the anti-splash net (E) to the front side of bottom base (B).


B: Fill the basin (B) with clean water, making sure the pump (C) is fully submerged.

Note: The maximum water level should be approximately 1.2 inches below the top edge of the basin (B).



Step 4: Finally, connect the plug of pump (C) to a GFCI outlet.

WARNING: Always disconnect the pump (C) before placing your hands in the water.



CARE AND MAINTENANCE

- To eliminate the possibility of water damage to areas around the fountain, check for leaks and excessive splashing after the initial set up of the fountain. It is highly recommended this fountain be placed in an area where it cannot be damaged.
- Do not leave the fountain running for extended periods of time when no one is present to observe the performance.
- Check the area around the fountain on a regular basis to ensure there is no leakage.
- Do not attempt to move fountain once filled with water.